

- o/ drawn with 18mm material. Quality plywood recommended
- 1/ uses Mark Audio CHN-110
- 2/ line all interior faces with damping material: SAE F10 felt, Ultratouch, acoustic fiberglass, or similar (shown in green)
- 3/ don't forget to relieve the back of the driver cutout with a chamfer or roundover
- 4/ bracing not shown but recommended. Braces should run in the direction of the line. Increase width to compensate for brace volume (30-35% holes)
- 5/ beveling front vertical edges recommended
- 6/ stabilizing plinth recommended



Kewel Compact ML-TL ov85  
 Mark Audio CHN-110 | 18mm plan  
 designed by S Lindgren | drawn by dld  
 24-april-2021  
 © 2017-21 Woden Design

