



Stranger ML-Voigt ov8

Tangband W8-1772 | 18mm plan
designed by S Lindgren | drawn by dld
06-december-2020
© 2017-2020 Woden Design

- 0/ drawn with 18mm material
- 1/ Lag back & one sidewall 1in OC-703 acoustic fibreglass board or its equivalent rockwool, SAE-F10 rated felt, jute carpet underlay or similar. Avoid egg-crate foam.
- 2/ don't forget to relieve the back of the driver cutout with a champher or roundover
- 3/brace not shown, but recommended, It should be vertical, brace the driver to the back of the cabinet and be just off-centre. If brace is 18mm wide would require an extra 12mm width.

